High-Definition Serial Digital Interface Multi Format OLED Monitor

User Manual



BVB(OLED) Series



User Manual 1 of 24

| CAUTION | 3 |
|--------------------------------------|----|
| FEATURES | 5 |
| CONTROLS, INDICATORS AND CONNECTIONS | 6 |
| MENU BASIC OPERATION | |
| PICTURE MENU | 11 |
| AUDIO MENU | |
| DISPLAY MENU | |
| GPI MENU | |
| SETUP MENU | 20 |
| INFO MENU | 22 |
| INPUT SUPPORT MODE | 22 |
| MECHANICAL DIMENSION | 24 |



Before operating the set, please read this manual carefully.

WARNING:

To reduce the risk of electric shock does not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel. To prevent fire or shock hazard, do not expose the rear of the set to rain or moisture. Do not rub or strike the Active Matrix LCD with anything hard as this may scratch, mark, or damage the Active Matrix LCD permanently.

Unauthorized tampering with the inside of the monitor invalidates the warranty.

The manufacturer shall not warrant for any damage caused by improper maintenance and/or repair. Work by third parties.

Important safeguards for you and your new product:

Your product has been manufactured and tested with your safety in mind. However, improper use can result in potential electrical shock or fire hazards. To avoid defeating the safeguards that have been built into your new product, please read and observe the following safety points when installing and using your new product and save them for future reference.

Read Instructions

Follow Instructions

All operating and use instructions should be followed.

Retain Instructions

The safety and operating instructions should be retained for future reference.

Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

Cleaning

Disconnect the unit from the electricity supply before cleaning. Do not use abrasive cleaners. Use a damp cloth for cleaning.

Water and Moisture

Do not use this apparatus near water.

Transporting Product

A product and cart combination should be moved with care. Quick stops, excessive force and uneven surfaces may cause the product and cart combination to overturn.

Attachments

Do not use attachments not recommended by **Boland** as they may cause hazards.

Ventilation

Do not block any of the ventilation openings.

Install in accordance with the manufacturer's instructions.

Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your supplying dealer.

Power Lead Polarization

This product is equipped with a three-wire grounding-type cord. This is a safety feature. Do not defeat the safety purpose of the grounding-type cord.

Power Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles and the point where they exit from the product.

Outdoor Cable Grounding



User Manual 3 of 24

Caution

If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. A "face plate" also needs to be installed with an isolating capacitor to prevent any damage from static.

Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent possible damage to the product due to lightning and power-line surges.

Power Lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to avoid contact with such power lines or circuits, as contact with them might be fatal.

Earthing the product

This product must be earthed properly to comply with the safety regulations in the country of use. If you are unsure of these regulations, please consult a qualified electrician.

Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltages or other hazards. Refer all servicing to qualified service personnel. If the Set does not operate properly, switch it off and call your dealer.

Damage Requiring Service

Isolate this product from the mains supply and refer servicing to qualified service personnel under the following conditions:

If the power-supply cord or plug is damaged.

If the glass front has been damaged.

If there is ingress of water between the glass and the LCD screen.

If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.

If the product has been dropped or the cabinet has been damaged.

If the product exhibits a distinct change in performance.

Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition and the front seal is intact.

Mounting

The product should be mounted on a wall only as recommended in the instructions.

Power

This set operates on an AC supply; the voltage is as indicated on the label on the Manual. This appliance must be earthed at all times through the chassis as well as through the power lead.



User Manual 4 of 24

Features

This product is the multi-format Digital LCD Panel to display various kinds of digital video input signal as HD/SD-SDI/DVI/HDMI Digital and analog signal such as Composite/S-Video/RGB/PC-RGB/ Component.

This is also High Definition Broadcasting Monitor which can make it available to do output of stable video signal with the menu of considering convenient user interface and the easy control for brightness and color, and by EQ function of HD-SDI input part.


- HD/SD SDI 2Input / 2Output.
- WAVEFORM / Vector Scope / Time code Display.
- Dual waveform display available
- 16 ch Audio Lever Meter Display. (SDI only)
- Analog & Digital Signal Audio Lever Meter Display.
- Lever Meter Position display selectable
- Dual Link MODE & 1080p 60 Compatible
- Closed Caption (Analog Signal only): CEA608, 708
- H/V Delay.
- · Audio Disembedder & Internal Speaker & Headphone out & Monitor out
- Color Temperature User, VAR, 9300K, 6500K, 5400K, 3200K
- Over Scan/Zero Scan/Under Scan/Pixel to Pixel
- PIP (Picture In Picture)/PIP Blend
- Tally LED function (Green/Red/AMBER)
- Integrated DVI (HDCP) function.
- HDMI (HDCP) function.
- Supports VESA DDC2B and a subset of VESA standards.
- Single board is suitable for mounting behind an LCD panel.
- Supported RS-232C, RS-422.
- Supported External GPI Control (RJ-45).
- OSD: Graphic based OSD, 7 Languages (UNICODE System).
- UMD
- Auto Calibration: CA-210, CA-310 (Minolta), K-10 (Klein)
- 10bits 3D LUT Color Calibration (BT.709, SMPTE-C, EBU, NTSC, D-Cinema)
- ETHERNET: Network System Controller / Update




User Manual 5 of 24

Controls, Indicators and Connections

BVB25 Front



BVB25 Rear





User Manual 6 of 24

Controls, Indicators and Connections

Front Keys Operations

STANDBY

Power ON/OFF Button. This button is operated after being pressed about 3 seconds.

SDI 1 / SDI 2

Select SDI 1/SDI 2 source directly

Composite

Select ANALOG source directly('CVBS1' -> 'CVBS2' -> 'CVBS3')

DVI

Select DVI source directly

HDMI

Select HDMI source directly

FUNCTION 1 ~ 6

Executes functions of user selected

(Undefined, Scan, Marker, Level Meter, Waveform, Aspect, H/V Delay, Time Code, Color Only, Audio Group, Audio Channel, Audio mute, Still image, Caption, False Color, Aspect/Area Marker, PIP func & Input, Zoom, Gamma Select, WFM Line Select)

MENU

Activates main OSD menu Navigates higher menu in main OSD menu Exits OSD menu

DOWN

Decreases sound volume of speaker

Decreases values of user menu in main OSD menu

Executes function (by OSD help commands) in main OSD menu

UP

Increases sound volume of speaker.
Increases values of user menu in main OSD menu
Executes function (by OSD help commands) in main OSD menu

SEL/INPUT

Activates OSD menu of input source selecting Changes input source by selecting Executes functions (by OSD help commands) in main OSD menu Activates child menu

ADJUST

Adjust Picture Menu (Brightness -> Contrast -> Color -> Sharpness->Phase & Tint)
Turn Right (with 'UP' button is same)
Turn Left (with 'DOWN' button is same)



User Manual 7 of 24

Controls, Indicators and Connections

REAR Panel

• SDI 1/SDI 2 IN HD SDI / SD SDI Input

• SDI 1/SDI 2 OUT SDI 1, SDI 2 Loop Out

RS-232C IN

Update /Auto color calibration

DVI-I

DVI-I Type Digital / Analog PC-RGB Video Input

HDMI

High Definition Multimedia Input

CVBS1/Pr/R In

CVBS 1, Component Pr, GBR(SOG sync) R Input

CVBS2/Y/G/Y In

CVBS 2, Component Y, GBR(SOG sync) G, S-Video Y Input

CVBS3/Pb/B/C In

CVBS 3, Component Pb, GBR(SOG sync) B, S-Video C Input

AUDIO IN

DVI-I/Component/GBR/CVBS1,2,3/S-Video Sound Input

AUDIO OUT

AUDIO MONITOR OUT

ETHERNET

Network System Control/ Firmware Upgrade


GPI

GPI 1 ~ 7 Control Port

RS422 IN/OUT

Monitor System Control

DC 24V



| PIN NO | Description |
|--------|-------------|
| 1 | GND |
| 2,3 | |
| 4 | + 24 V |



User Manual 8 of 24

MENU Basic Operation

In this menu system, there are several ways to customize the menu settings provided.

Most menus consist of three levels to set up the options, but some require greater depth for the variety of settings. If you press the **MENU** button, only the first and second level of the menu system will appear on the monitor screen. The third level can be displayed by pressing **SEL/INPUT**. If a menu has more than three levels, the pop-up dialogue box will be displayed as the fourth or fifth level.

To show and remove the Menu

Press the **MENU** button to display the menu. A second press of the **MENU** button will take you back to monitor viewing.

To go to the next level

Press SEL/INPUT button.

To go back to the previous level

Press **MENU** button











Typical Menu Operation

- 1. Press **MENU** button: The main menu will appear.
- 2. Use **UP/DOWN** button to select the desired menu option (icon).
- 3. While the desired menu option is selected, press SEL/INPUT to move to the second level.
- 4. Use **UP/DOWN** button to select the second menu option.
- 5. Press **SEL/INPUT** to move to the third level: Some menu options require additional steps.
- 6. Press **MENU** to return to the previous menu to return to monitor viewing.

Turning On the Monitor

- 1. First, connect power cord correctly. At this moment, the monitor switches to standby or power on mode. In standby mode, in order to turn monitor on, press the **ST-BY** button.
- 2. Select the viewing source by using SEL/INPUT button on Keypad in front of monitor

Volume Adjustment


- 1. Press the UP/DOWN button on Keypad.
- 2. If you want to switch the sound off, press the FUNCTION (Audio mute) button.
- 3. You can cancel this function by pressing the FUNCTION (Audio mute) or volume control button.





MENU Basic Operation


On Screen Menus Language Selection



- Display -> OSD Set -> Language
- The menus can be shown on the screen in the selected language.
- Supported Language: English, Spanish, Portuguese, German, French, Italian

How to Select Video Source by OSD

- 1. Press the SET/INPUT button and then UP/DOWN button to select each video source.
- 2. Press the **SET/INPUT** button to go to desired video source.
- 3. If Input Name is enabled, The **SET/INPUT** button goes into input name edit mode instead of selecting source.





User Manual 10 of 24

Video Menus of each Input modes








< Video (NTSC) Picture menu>

< PC Picture menu>

< SDI, HDMI Picture menu>


Adjust



- Adjust the values of Brightness, Contrast, Color, Tint and Sharpness directly from -50 to 50

Contrast, Brightness, Sharpness, Color (All Sources), Tint (without PC, DVI, HDMI, Component), Phase (Component).


Color Temperature Control





- For Setting the Color temperature or adjusting RGB Gain/Offset value directly
- User (User setting RGB gain value), VAR(3200K ~ 11000K), Often used value(11000K, 9300K, 6500K, 5400K,3200K) and 3D LUT Calibration value(D65 6504K/C-6774K/D-Cinema 6302K)
- -Color Space: Native/BT.709/SMPTE-C/EBU/NTSC/D-Cinema

SCAN



- 1. Over Scan 95% input size and fit the selected display size
- 2. Zero Scan 100% Input size and fit the selected display size
- 3. Under Scan 105% Input size and fit the selected display size
- 4. Pixel to Pixel Display size is an input size. If input resolution is bigger than panel size, fit the panel size

User Manual 11 of 24




Aspect Ratio




- For setting the aspect ratio.
- Full Screen: The images are displayed with a panel size.
- Full Screen, 16:9, 4:3, 14:9, 13:9, 1.85:1, 2.35:1: The images are displayed with each aspect ratio.
- Function-key operate Rotation, Full Screen, 16:9, 4:3, 14:9, 13:9, 1.85:1, 2.35:1
- AFD function Added
- PC mode: Full Screen & 4:3 only

Zoom



- Can see the enlarged picture by (2X, 3X, 4X, 5X) ratios.
- If user select the Zoom 2X, can see the below yellow box in picture.
- Press Select or Enter button, user can see the enlarged picture.
- Menu key escape the zoom mode.

Picture Option



I/P Mode

- → Line Doubler/inter-Field/Field Merge function on/off
 - Gamma Select
- →Gamma Level Select (0.8 ~ 3.0)
 - Back Light
- →Inverter dimming Level select (0~100)

Color Only

- → Mono Color/Blue only Function on/off
- Mono color: For selecting monochrome images.
- Blue Only: Images have only blue color expect red and green color
 - False Color
- →False Color: on/off
 - Patterns
- →Auto Run, 100% Color Bars, 75% Color Bars, Luma, RGB, White, Black, RED, Blue, Green
 - HV Delav
- \rightarrow Off//H/V/H+V
 - Output Range
- →Normal (16~235)/Full (0~255)
 - Noise Reduction
- -Noise Reduction on/off. (NR is for Video signal (HD-SDI, CVBS, S-Video and Y.Pb.Pr) & DTV timing.
 - NTSC Setup(Only Video mode)
- IRE value under NTSC mode between 0 IRE and 7.5 IRE.




User Manual 12 of 24

PIP (Picture IN Picture)

- Watch two programs or source at the same time. And set up PIP size and position.

PIP on/off



- Control PIP function On/Off.

Input Source

- PIP input Source can operate with different signal and type.
- Analog (CVBS 1, 2, 3, Y.Pb.Pr, GBR, PC) inputs + Digital (DVI, HDMI) + SDI (SDI1, SDI2) inputs
- -SDI + SDI input PIP


Ex) AV + S-Video (X), DVI + SDI (O), PC + DVI (O), SDI1+SDI2 (O)

- PIP MATRIX TABLE

| | SDI 1 | SDI 2 | HDMI-DVI | PC_YPbPr_RGB_YC_CVBS |
|----------------------|-------|-------|----------|----------------------|
| SDI 1 | Х | 0 | 0 | 0 |
| SDI 2 | 0 | Х | 0 | 0 |
| HDMI-DVI | 0 | 0 | X | 0 |
| PC_YPbPr_RGB_YC_CVBS | 0 | 0 | 0 | X |

Aspect Ratio

- Choose PIP size of Small/POP1/POP2



Position



- Choose the pip position on the each corner of the pane

PIP Blend

-Blend to PIP size of Small(0~100)

PIP Swap


- Using Swap option, you can exchange two programs or source at the same time.



User Manual 13 of 24

PICTURE MENU

PC Menu




- Only operate PC input mode
- Select Auto-adjust and adjust Phase, HV position, Frequency
- Auto-Adjust automatically set the optimum values of Phase, HV position and Frequency.
- -Selects X768 native PC video timings. (Auto/1024x/1280x/1360x/1366x)

Dual Link Mode (SDI only)



-Dual Link Mode select. (Auto/Off/RGB444/YCbCr444/YCbCr422)

Peaking Filter



- -Peaking Filter: Peaking Filter On/Off.
- -Peaking Color: Red/Blue/White/Violet.
- -Peaking Level: 0~100.

⊕boland

User Manual 14 of 24

Audio Output




- Select Internal Speaker out. (Auto/SDI1/SDI2/HDMI/Line in)

Audio Selection

-PIP & W/F Double mode only. Select the Main or Sub.

SDI out



-SDI Audio output Group & Channel source select

SDI Gr/Ch

- Audio output Group source select. (Group1, 2, 3, 4)
- Audio output Channel source select. (Channel1~16, Channel1/2,3/4,5/6,7/8,9/10,11/12,13/14,15/16 off)

SD2 Gr/Ch

- Audio output Group source select. (Group1, 2, 3, 4)
- Audio output Channel source select. (Channel1~16, Channel1/2,3/4,5/6,7/8,9/10,11/12,13/14,15/16 off)

Volume








- Adjust the speaker or headphone Volume level.

User Manual 15 of 24



Marker

Aspect



- 16:9, 4:3, 14:9, 13:9, 1.85:1, 2.35:1, 1.85:1&4:3, Custom fitted panel size marker on screen.

Area

- Area: Draw dotted line Marker on screen in case of images. (16:9 95/93/90/88/80%, 4:3 95/93/90/88/80%, EBU Action 16:9/14:9/4:3, EBU Graphic 16:9/14:9/4:3)

Center Maker

- "+" Marker on center of screen
 - Aspect L. Color
- -Marker Line Color Select. (WHITE, YELLOW, BLUE, RED, BLACK)
 - Area L. Color
- -Area Line Color Select. (WHITE, YELLOW, BLUE, RED, BLACK)
 - Line Width
- Marker line thickness setting. (0~10)
 - Custom Marker
- -The user wants Marker size setting. (Below panel size)

Waveform




- Enable
- Off / Y+VT / Y+Cb+Cr/ G+B+R /Double
 - Key Format
- Press the **W/F** button to display the WAVEFORM Mode. (Rotation, Y+VC, Y+Cb+Cr, G+B+R, Double)
 - Line Select
- Select line WAVEFORM & Vector Scope display.
 - Line Number

-Line select: Input Resolution size.

Line Display

-off/on/5 sec

Level Meter







- Display the audio level meter on screen in SDI input.
- Audio level meter cannot display with OSD.



User Manual 16 of 24

DISPLAY MENU

- Type
- -Pair: Respectively Channel with right and left display
- -Group: Respectively group display
 - Position
- Level Meter Position selects. (
- Scale



 Level Meter Scale mode selects.
 (Digital/Nordic/BBC/EBU/DIN/Expanded DIN/SMPTE VU/EBU VU/France VU)

Time code




- Enable
- Time code Display (off/LTC/DVITC, SDI only)
 - Size
- -Time code size select. (Small, Middle, Large)
 - Position
- Time code display position selects (L-T, C-T, R-T, L-B, C-B, R-B)
- Transparency
- Disable blending Time code background with video image. (0%, 25%, 50%, 75%, 100%)
 - DVITC Line
- -Auto, Line 1 ~ 31

Caption



- Caption
- -608 Line21, 608 ANC, 608 Transcoded, 708 mode Select
 - 608 Caption
- -608 Caption mode Select. (C/C1, C/C2, C/C3, C/C4, TEXT1, TEXT2, TEXT3, TEXT4, OFF)
 - 708 Caption
- -708 Service mode Select. (Service 1/Service 2)

OSD Set




- Language
- -Select a language for the menus to appear in. (English, Spanish, Portuguese, German, French, Italian)
 - Position
- L-T, R-T, C, L-B, R-B
 - Transparency
- Disable blending OSD background with video image.


- Timeout
- OSD gone time setting. (3~200)

User Manual 17 of 24



U.M.D






Tally Green

- UMD
- UMD display on/off
 - Character
- UMD Character Select
 - Position
- UMD display position select. (L-T, C-T, R-T, L-B, C-B, R-B)
 - FG Color
- UMD Character color Select (RGB_255_192_128_0_Transpareut)
 - BG Color
- UMD BG color Select (RGB_255_192_128_0_Transpareut)

Input I.D.



- Input ID
- source Message display.
 - ID Style
- select "Input Format"/"Custom Label"
 - Input Label
- Display user made name instead of input source name on source OSD and message OSD.

Video Range



- -Range Check: Range Check on/off.
- -Y Max: Maximum luminance level.
- -Y Min: Minimum luminance level.
- -C Max: Maximum chroma level.
- -C Min: Minimum chroma level.
- -Color: Black/Blue/Red/Green
- -Grid: Grid line on/off
- -Blink: Y/C Min-Max to blink.(0~7)



User Manual 18 of 24

Remote MENU





GPI Control & GPI#

- For allocating functions to particular GPI pins.
- When remote control operations are to be performed using the GPI Controller.
- GPI Control: GPI function Enable/Disable
- GPI 1 ~ 7

| GPI Function | Description | |
|--|--|--|
| Undefined | Not set (no function allocated) | |
| Tally R, Tally G | For lighting up the Red or Green tally lamp. | |
| Marker On/Off | Displays the marker. | |
| Function 1~6 | Activates FUNCTION 1~6 buttons | |
| Scan | Over Scan/Zero Scan/Under Scan/ Pixel to Pixel | |
| Aspect | Sets the aspect ratio of the images | |
| Waveform | Activates WAVRFORM & Vector Scope (SDI | |
| Wavelonn | Only) | |
| Aspect Marker | Marker size Select. | |
| Area Marker | Area Marker size Select. | |
| Center Marker | Displays the center marker. | |
| Input CVBS 1,2,3, Input G.B.R, Input SDI | Switches the input source. | |
| 1, Input SDI 2, Input Y.Pb.Pr , Input PC , | | |
| Input DVI, Input HDMI | | |
| Menu Key, Enter Key, Up Key, Down Key | Use the key function by GPI. | |
| Left Key, Right Key | Ose the key function by GF1. | |
| GPI 7 : Power Key(Fixed) | | |




User Manual 19 of 24

Setup Load & Setup Save

- Setup Load: Load user saved values or default value
- Setup Save: Save user setting values at user 1, 2, 3.


Function Switch



- Function 1~6: Select the function to be allocated to the FUNCTION
 1~6 buttons

| Function1&2 button | Description |
|----------------------|---|
| Undefined | Not set (no function allocated) |
| Scan | Over Scan/Zero Scan/Under Scan/ Pixel to Pixel |
| Marker | Marker on/off |
| Level Meter | Level Meter on/off |
| Waveform | Waveform on/off |
| Aspect | Sets the aspect ratio of the images |
| H/V Delay | H Delay -> V Delay -> HV Delay -> off |
| Time Code | Time Code on/off. |
| Color Only | Execute Mono color or Blue Only |
| Audio Group | Select the extract the embedded audio group in SDI input. |
| Audio Channel | Select the extract the embedded audio channel in SDI input. |
| Audio Mute | Toggles sound status of speaker/headphone in mute. |
| Still image | Toggles picture status between motion and still image. |
| Caption | Caption on/off. |
| False Color | False Color on/off |
| Aspect / Area Marker | Aspect/ Area Marker Select |
| PIP func & Input | PIP func & input Select |
| Zoom | Zoom function on/off |
| Gamma Select | Gamma Select |
| WFM Line Select | WFM Line select function on/off |

Control



Front LED

- Front LED on/off
 - Local Enable
- -Power, up and down key is only worked, if Local enable is off.
 - Remote Enable
- Select the controller of local or remote. If remote controller is selected, both local (front key) and remote are worked. However select local, local key only operated.

Auto Key Lock

- If it does not work 10 minutes to lock automatically. Key button is operated after being pressed about 2 seconds




User Manual 20 of 24

SETUP MENU

- Source Key (Front "Input" Button/ Remote Controller "Source" Button)
- -Menu: Select the input signals to the input menu OSD.
- -Rotate: Press Button to rotate the input source.
 - Auto Source
- When there is no input signal, Auto Source change.

Communication



Type

- -Select the Communication: RS-422 or Lan
 - Baud Rate 422 Baud Rate
- 2400/4800/9600/19200/38400/57600/115200
 - Serial Protocol_422/Lan Protocol
- -Basic / TSL 5.0 / TSL 4.0 / RDU/ Extension
 - ID (01~99)
- If control each Board, must set ID numbers of each Board

IP Config



Load Network Settings

-ETHERNET cable connected after "Enter". (ID/IP Address/Gateway/Subnet Load)

- DHCP
- -DHCP on/off (Manual IP settings DHCP on)
- * "Apply" enter all settings after.

Screen Saver



Blue Screen

- Enables screen saver functions to avoid panel burning.
 - BG Gray
- Select gray level on besides display picture. (0~7)
 - Power Save
- DPMS (Display Power Management Signaling) Power Save Mode.

Fan Control

- Fan Control
- Internal Fan Controls driving option by temperature sensor Auto / force on / force off
 - Active Temp
- Adjusts fan driving temperature by Celsius degree. It works only when the Fan Control setting is Auto.
 - Hysteresis
- Adjusts fan driving hysteresis temperature by Celsius degree. (1~10℃)
 - Shutdown
- For a monitor protection is above of 75 \mathcal{C} , Power Off.

Sync Check Period

- Sync Check Period at when switching the input signal (10 ~ 300 ms)



User Manual 21 of 24

Info MENU



- Model, H/W Version, FPGA,F/W Release, Operating Time, Cal. ID

Input Support Mode

Support Signals

| Items | | Specifications | | |
|-----------|----------------------------|---------------------------------------|--|--|
| | Serial Digital Interface | HD SDI- 2.970Gbps | | |
| | | SD HDI- 270Mbps | | |
| | HDMI DVI-I (DVI+VGA_IN) | H Frequency Range : 20~82 kHz | | |
| | | V Frequency Range : 55 ~ 90 Hz | | |
| | | Maximum resolution :1920x1080 60Hz | | |
| | | Maximum pixel rate : 162 MHz | | |
| | | DTV mode support : 720P, 1080i, 1080p | | |
| Supported | ANALOG RGB | H Frequency Range : 20~82 kHz | | |
| Signals | | V Frequency Range : 55 ~ 90 Hz | | |
| | | Maximum resolution : 1920x1080 60Hz | | |
| | | Maximum pixel rate : 162 MHz | | |
| | | DTV mode support: 720P/1080i/1080p | | |
| | | SOG sync support | | |
| | ANALOG Component (DTV/DVD) | 1080p/1080i/720P/480i/576i/480P/576P | | |
| | CVBS | NTSC/PAL/SECAM | | |

Support Timings

• SDI Input

| SMPTE-428.1M | 2048x1080P(24/25) |
|---------------------|---|
| SMPTE-425M(3G) | 1920x1080P(50/60) |
| SMPTE-260M | 1920x1035i(60/59.94) |
| SMPTE-259M | 1920x1080i(50) |
| SMPTE-274M | 1920x1080i (50/59.94/60) |
| SIVIF I L-2 I 4 IVI | 1920x1080P (30Psf/25Psf/24Psf/30/25/24) |
| SMPTE-296M | 1280x720P (24/25/30/50/59.94/60) |
| SMPTE-125M | 480i(59.94) |
| ITU-R BT.601 | 576i(50) |



User Manual 22 of 24

Input Support Mode

• PC & DVI Input

| Section | Resolution | H Frequency(kHz) | V Frequency(Hz) | Pixel Frequency(MHz) | Comment | | |
|---------|------------|--------------------|-------------------|------------------------|---------|--|--|
| | 640x400 | 37.861 | 85.08 | 31.5 | | | |
| | 640x350 | 31.469 | 70.087 | 25.175 | | | |
| | 640x350 | 37.861 | 85.08 | 31.5 | | | |
| | 640x480 | 31.469 | 59.94 | 25.175 | | | |
| | 640x480 | 35.000 | 66.667 | 30.24 | | | |
| | 640x480 | 34.940 | 69.884 | 28.513 | | | |
| | 640x480 | 37.861 | 72.809 | 29.765 | | | |
| | 640x480 | 37.500 | 75.0 | 31.5 | | | |
| | 640x480 | 43.269 | 85.008 | 36.0 | | | |
| | 640x480 | 45.540 | 90.0 | 37.889 | | | |
| | 720x400 | 31.469 | 70.087 | 28.322 | | | |
| | 720x400 | 37.927 | 85.039 | 35.5 | | | |
| | 800x600 | 35.156 | 56.25 | 36.0 | | | |
| | 800x600 | 37.879 | 60.317 | 40.0 | | | |
| | 800x600 | 43.764 | 70.02 | 45.513 | | | |
| | 800x600 | 48.077 | 72.188 | 50.0 | | | |
| | 800x600 | 46.875 | 75.0 | 49.5 | | | |
| | 800x600 | 53.674 | 85.061 | 56.25 | | | |
| | 800x600 | 56.880 | 90.0 | 60.065 | | | |
| | 832x624 | 49.726 | 74.551 | 57.284 | | | |
| PC | 1024x768 | 48.780 | 60.001 | 64.11 | | | |
| | 1024x768 | 48.363 | 60.004 | 65.0 | | | |
| | 1024x768 | 56.476 | 70.069 | 75.0 | | | |
| | 1024x768 | 57.703 | 72.039 | 78.476 | | | |
| | 1024x768 | 60.241 | 74.927 | 81.724 | | | |
| | 1024x768 | 60.030 | 75.029 | 78.75 | | | |
| | 1024x768 | 68.677 | 84.997 | 94.5 | | | |
| | 1024x768 | 72.810 | 90.0 | 100.187 | | | |
| | 1152x864 | 53.700 | 60.0 | 81.624 | | | |
| | 1152x864 | 62.932 | 69.924 | 96.663 | | | |
| | 1152x864 | 67.500 | 75.0 | 104.993 | | | |
| | 1152x870 | 68.681 | 75.062 | 100.0 | | | |
| | 1152x900 | 61.846 | 66.0 | 94.787 | | | |
| | 1152x900 | 72.713 | 76.047 | 105.561 | | | |
| | 1280x720 | 47.760 | 60.0 | 74.481 | | | |
| | 1280x720 | 52.500 | 70.0 | 89.040 | | | |
| | 1280x720 | 54.072 | 72.0 | 91.706 | | | |
| | 1280x720 | 56.400 | 75.0 | 95.654 | | | |
| | 1280x768 | 60.150 | 75.0 | 102.977 | | | |
| | 1280x960 | 60.000 | 60.0 | 102.104 | | | |
| | 1280x960 | 59.640 | 60.0 | 102.104 | | | |





User Manual 23 of 24


| | 1280x1024 | 63.337 | 59.978 | 108.18 | |
|-----|-----------|--------|--------|---------|-------------|
| | 1280x1024 | 63.981 | 60.02 | 108.0 | |
| | 1280x1024 | 64.754 | 60.06 | 108.992 | |
| | 1280x1024 | 63.600 | 60.0 | 108.883 | |
| | 1360x768 | 47.700 | 60.0 | 84.700 | |
| | 1600x1200 | 75.000 | 60.0 | 162.000 | |
| | 720x480 | 15.735 | 59.94 | 13.500 | Interlaced |
| | 720x576 | 15.735 | 50.0 | 13.595 | Interlaced |
| | 720x480 | 31.469 | 59.94 | 25.175 | |
| | 720x576 | 31.250 | 50.0 | 26.566 | |
| DTV | 1280x720 | 44.964 | 59.94 | 74.176 | |
| DIV | 1280x720 | 37.500 | 50.0 | 60.466 | |
| | 1920x1080 | 33.750 | 60.0 | 74.25 | Interlaced |
| | 1920x1080 | 28.125 | 50.0 | 70.723 | Interlaced |
| | 1920x1080 | 31.250 | 50.0 | 72.000 | Interlaced |
| | 1920x1080 | 67.5 | 60 | 148.5 | Progressive |

Mechanical Dimension

BVB25









User Manual 24 of 24